

Gas Oil Change & Fuel Saver

For complete maintenance – refer to operating manual



semi-synthetic oil

Performance



Install BG Quick Clean (105C) in the crankcase to remove contaminants, free piston rings and restore compression.



Install BG MOA (110C) with fresh engine oil. Prime all engine passages with fresh, new oil. Install new oil filter.



Install BG CF5 (203C) in the fuel system for deposit control. Lubricate chassis, top off fluid and perform maintenance check.

From **\$125^{.95}**

Premier



Drain old engine oil and install BG MOA (110C) with new engine oil. Install new oil filter.



Install BG CF5 (203C) in the fuel system for deposit control. Lubricate chassis, top off fluids and perform maintenance check.

From **\$95^{.95}**

Basic



Drain old engine oil and install BG MOA (110C) with new engine oil. Install new oil filter, lubricate chassis, top off fluids and perform maintenance check.

From **\$80^{.95}**

Environmental, Provincial and Federal taxes extra. Hemi engine extra.